

LEARNING OUTCOMES

At the end of this module the student be able to:

- 1. Create system credentials with administrative privileges on Windows 7.
- 2. Install essential drivers for hardware components.
- 3. Configure wired and wireless network connections.
- 4. Troubleshoot common issues related to system credentials, drivers, and network

MODULE CONTENTS

- 4 Creating System Credentials
- 5 Installing Essential Drivers
- 7 Network Configuration
- 10 Assessment Task

CREATING SYSTEM CREDENTIALS

Creating system credentials on Windows 7 typically involves creating a user account with administrative privileges. These credentials are necessary for tasks that require elevated permissions, such as installing software, making system changes, or accessing certain files.

Note: You will need administrative privileges to create new user accounts. Make sure you are logged in as an administrator or have administrative rights to perform these steps.

1. Open User Accounts:

- Click on the **Start** button in the bottom-left corner of your screen.
- Type "Control Panel" in the search box and press **Enter**.
- In the Control Panel, click on the "User Accounts" option.

2. Create a New User Account:

 In the User Accounts window, you'll see a link that says "Manage another account." Click on it.

3. Add a New User Account:

• Click on the "Create a new account" link.

4. Enter Account Details:

- Provide a name for the new account. This can be a descriptive name like "SystemAdmin."
- Choose whether the account should be a "Standard user" or an "Administrator." For system credentials, select "Administrator" to grant administrative privileges to this account.
- Click the "Create Account" button.

5. Set a Password (Optional):

- You can set a password for the new account if desired. It's recommended to set a
 password to secure the account.
- To set a password, click on the newly created account in the Manage Accounts window and then select "Create a password."

6. Log into the New Account:

- Log out of your current user account or restart your computer.
- On the Windows 7 login screen, you should see the newly created account.

7. Initial Configuration:

 When you log in with the new account for the first time, you may need to go through an initial setup process.

8. Using the New Account:

Once logged in, you now have a new user account with administrative privileges. You
can use this account for tasks that require elevated permissions.

Important Notes:

- Be cautious when using an administrator account, as it has full control over the system.
 Only use it for tasks that require administrative access and avoid using it for regular everyday activities.
- Make sure to keep the password of the administrator account secure and memorable, as it
 is essential for system maintenance and security.
- Always log out of the administrator account when you're done with administrative tasks
 and switch back to a standard user account for normal use. This helps protect your system
 from unintended changes.

Remember that Windows 7 reached its end of support on January 14, 2020. It is recommended to upgrade to a more recent and supported version of Windows for security reasons, as Windows 7 no longer receives security updates from Microsoft.

INSTALLING ESSENTIAL DRIVERS

Installing essential drivers on Windows 7 is crucial to ensure that your hardware components work properly. Here's a step-by-step guide on how to install essential drivers:

Note: Before you begin, make sure you have the necessary driver installation files or access to the internet to download drivers. Drivers are often available on the manufacturer's website.

1. Access Device Manager:

- Click on the **Start** button in the bottom-left corner of your screen.
- Right-click on **Computer** and select **Manage** from the context menu.

• In the Computer Management window, expand the "System Tools" category on the left, and then click on **Device Manager**.

2. Identify Missing Drivers:

• In Device Manager, you'll see a list of hardware categories with devices that may have missing drivers. These devices will typically have a yellow triangle icon next to them.

3. Download Drivers:

- Visit the official website of your computer's manufacturer (e.g., Dell, HP, Lenovo) or the component manufacturer's website (e.g., NVIDIA, Intel, AMD).
- Look for a "Support" or "Drivers" section on the website.
- Enter your computer's model number or select the appropriate hardware category and model to find the drivers.
- Download the latest drivers for each hardware component with missing drivers. Make sure to choose drivers compatible with Windows 7.

4. Install Drivers:

- After downloading the driver files, run the installer for each driver.
- Follow the on-screen instructions to install the drivers. This may involve accepting license agreements, specifying installation paths, or restarting your computer.

5. Windows Update:

- In some cases, Windows Update may automatically detect and install certain drivers.
 Make sure your computer is connected to the internet and check for updates.
- Go to Control Panel > System and Security > Windows Update.
- Click on "Check for updates" and let Windows search for any available driver updates. If it finds any, follow the prompts to install them.

6. Graphics Drivers:

Graphics drivers (e.g., NVIDIA or AMD) may require special attention. It's often best to download and install them directly from the manufacturer's website to ensure you have the latest version for optimal performance.

7. Restart Your Computer:

 It's good practice to restart your computer after installing driver to ensure that the changes take effect.

- 8. Verify Driver Installation:
 - Return to Device Manager to confirm that all devices now have drivers installed correctly. The yellow triangles should be gone.
- 9. Test Hardware:
 - Test the functionality of your hardware components to ensure they are working correctly.
- 10. Backup and Driver Maintenance:
 - Consider creating a backup of your drivers using a tool like DriverBackup! to easily restore them if needed in the future.
 - Periodically check for driver updates, especially for critical components like graphics cards and network adapters.

You should be able to install essential drivers by following these steps for your hardware components on a Windows 7 system and ensuring optimal performance and functionality.

NETWORK CONFIGURATION

Configuring a network in Windows 7 involves setting up network connections both wired and wireless and adjusting network settings.

Wired Network Configuration:

- 1. Connect Hardware:
 - Ensure your computer is connected to your router or modem using an Ethernet cable.
- 2. Open Network and Sharing Center:
 - Click on the **Start** button in the bottom-left corner.
 - Click on Control Panel.
 - In the Control Panel, click on **Network and Sharing Center**.
- 3. Set Up a New Connection or Network:
 - In the Network and Sharing Center, click on "Set up a new connection or network."
- 4. Choose a Connection Type:
 - Select "Connect to the Internet" and click **Next**.
- 5. Choose a Broadband (PPPoE) Connection (If Required):

• If your internet connection requires a username and password (e.g., PPPoE), select this option and follow the on-screen instructions to enter your credentials.

6. Connect to the Network:

• Windows will attempt to connect to the internet using the configured settings.

Wireless Network Configuration:

1. Ensure Wireless Adapter is Enabled:

- Make sure your computer's wireless adapter is turned on. Most laptops have a physical switch or keyboard shortcut to enable/disable wireless.
- 2. Open Network and Sharing Center:
 - Follow the same steps as mentioned above for opening the Network and Sharing Center.
- 3. Manage Wireless Networks:
 - In the Network and Sharing Center, click on "Manage wireless networks" in the lefthand panel.
- 4. Add a Wireless Network:
 - Click on "Add" to add a new wireless network.
 - Windows will detect available wireless networks.
- 5. Select Your Network:
 - Choose your wireless network from the list and click **Next**.
- 6. Enter Network Key (Password):
 - If your network is secured with a password, enter the network security key (password) and click Next.
 - If the network is open, you'll connect without needing a password.
- 7. Connect Automatically:
 - You can choose whether to connect automatically when the network is in range.
- 8. Connect to the Network:
 - Click **Next** to complete the setup and connect to the wireless network.

Network Configuration and Settings:

- 1. Change Adapter Settings:
 - In the Network and Sharing Center, click on "Change adapter settings" on the left.
- 2. Configure Network Properties:
 - Right-click on the network connection you want to configure (e.g., Ethernet or Wi-Fi) and select "Properties."
 - Here, you can configure IP settings, DNS settings, and other properties. For most home networks, you can leave these settings as automatic (DHCP).
- 3. Advanced Network Settings:
 - In the network connection properties, click on the "Advanced" button to access more advanced network settings.
- 4. Configure Sharing and Discovery:
 - In the Network and Sharing Center, click on "Change advanced sharing settings" to configure file and printer sharing, network discovery, and public folder sharing.

You should be able to configure both wired and wireless network connections by following the steps mentioned above and customize network settings on your Windows 7 computer.

Remember to keep your network security settings secure by using strong passwords and encryption for wireless networks.

ASSESSMENT TASK

Activity 1: Creating System Credentials (Duration: 30 minutes)

Objective: Create a new user account called "**sudo**" with administrative privileges on a Windows 7 computer.

Instructions:

- 1. You will be provided with a Windows 7 virtual machine.
- 2. Create a new user account with administrative privileges.
- 3. You should set a secure password for the account.
- 4. Once the account is created you should log in using the new credentials.
- 5. Demonstrate the ability to switch between user accounts.

Grading Rubrics:

Criteria	Excellent (4)	Proficient (3)	Basic (2)	Limited (1)
Successfully	Created an	Created an account	Created a user	Failed to create a
created a new	account with	with	account but	new user account.
user account	administrative	administrative	lacked	
	privileges and	privileges.	administrative	
	follow name		privileges.	
	define in the			
	problem.			
Set a secure	Set a strong,	Set a secure	Set a password	Failed to set a
password for	complex	password that	but it lacks	password.
the account	password that	meets basic	strength or	
	adheres to	security standards.	security	
	security best		considerations.	
	practices.			
Successfully	Logged in	Logged in	Logged in but	Failed to log in
logged in	successfully	successfully using	encountered	using the new
using the new	using the new	the new	difficulties during	credentials.
credentials	credentials	credentials with	the login process.	
	without any	minor issues.		
	issues.			

Demonstrated	Successfully	Successfully	Managed to	Demonstrated an
the ability to	demonstrated	switched between	switch between	inability to switch
switch	the ability to	user accounts with	user accounts but	between user
between user	switch between	ease.	encountered	accounts.
accounts	user accounts		minor difficulties.	
	seamlessly			

Activity 2: Installing Essential Drivers (Duration: 30 minutes)

Objective: Identify missing drivers and download the necessary drivers if needed. Install them for hardware components on a Windows 7 computer.

Instructions:

- 1. Identify missing drivers in Device Manager.
- 2. Search and download the necessary device drivers from manufacturer websites.
- 3. Install the drivers following installation prompts and options.
- 4. Verify successful driver installation.

Grading Rubrics:

Criteria	Excellent (4)	Proficient (3)	Basic (2)	Limited (1)
Successfully	Successfully	Identified some	Identified only a	Failed to identify
identified	identified	missing drivers but	few missing	missing drivers in
missing	missing drivers	missed others,	drivers and lacked	Device Manager.
drivers	for the majority	indicating a partial	a clear	
	of hardware	understanding of	understanding of	
	components in	the process.	the hardware	
	Device		components.	
	Manager.			
Located and	Successfully	Located and	Had difficulty	Failed to locate
downloaded	located and	downloaded some	locating and	and download
the necessary	downloaded the	drivers, but some	downloading the	necessary drivers
drivers	majority of	were incorrect or	necessary drivers,	from
	necessary	incompatible.	resulting in some	manufacturer
	drivers from		incorrect	websites.
	manufacturer		downloads.	
	websites.			

Properly	Installed the	Installed some	Installed only a	Failed to install
installed the	majority of	drivers but	few drivers with	any drivers
drivers	drivers without	encountered	significant issues	successfully.
	major issues	difficulties or	or errors during	
		made errors during	the installation	
		installation.	process.	
Verified	Successfully	Verified the	Encountered	Failed to verify
successful	verified the	successful	difficulties	the successful
installation	successful	installation of	verifying the	installation or
	installation of	some drivers but	installation of	functionality of
	the majority of	had difficulty	most drivers and	any drivers.
	drivers, with	confirming the	their	
	some minor	functionality of	functionality.	
	issues.	others.		

Activity 3: Network Configuration (Duration: 1 hour)

Objective: Configure both wired and wireless network connections on a Windows 7 computer.

You need two Windows 7 virtual machines in this activity to configure networks.

Instructions:

- 1. Setup a wired network connection and configure IP and DNS settings.
- 2. You should also configure a wireless network connection with security settings (WPA2) if available.
- 3. Troubleshoot common wired and wireless network issues.
- 4. Configure network sharing and discovery settings.

Grading Rubrics:

Criteria	Excellent (4)	Proficient (3)	Basic (2)	Limited (1)
Successfully	Successfully set	Set up a wired	Managed to set	Failed to set up a
set up a wired	up a wired	connection but	up a wired	wired network
network	network	made minor errors	connection but	connection
connection	connection with	in IP or DNS	with significant	correctly.
with	correct IP and	configuration.	errors in IP or	
configured IP	DNS settings.		DNS settings.	
and DNS				
settings				

Configured a	Successfully	Configured a	Set up a wireless	Failed to
wireless	configured a	wireless	connection with	configure a
network	wireless	connection with	security but with	wireless network
connection	network	security but may	notable security	connection
with	connection with	have missed some	weaknesses or	securely.
appropriate	appropriate	important settings.	errors.	·
security	security settings.			
settings				
Demonstrated	Successfully	Demonstrated	Attempted	Failed to
troubleshooting	troubleshooted	basic	troubleshooting	troubleshoot or
skills for	and resolved	troubleshooting	but had difficulty	resolve common
common	common	skills but	resolving	network issues
network issues	network issues	struggled with	common network	effectively.
	with efficiency.	some common	problems.	
		network issues.		
Configured	Successfully	Configured	Attempted to	Failed to
network	configured	sharing and	configure sharing	configure
sharing and	network sharing	discovery settings	and discovery	network sharing
discovery	and discovery	but encountered	settings but faced	and discovery
settings	settings for	minor issues or	difficulties or	settings
	effective device	missed some	made significant	effectively.
	communication.	configuration	configuration	
		options.	errors.	